



Product Code	Name & Description
--------------	--------------------


## Bracelets & Straps


	<p><b>WanderShield Bracelet</b>            Standard WanderShield bracelet.            Totally waterproof - can be worn in the shower or bath.            Includes 2x soft strap and 2x extra strong strap            12 month battery life - when the battery is running low the LED light on the bracelet will flash and the speaker will beep occasionally. This lets you know that it is time to fit a new bracelet. The old bracelet can be returned to Miracle for recycling.</p>
---	--


	<p><b>Standard Strap (Pack of 52)</b>            Standard soft strap            Continuously adjustable</p>
--	---


	<p><b>Extra Strong Strap (Pack of 40)</b>            Extra strong strap</p>
--	---

## WanderShield Doorway

	<p><b>WanderShield Doorway kit</b>            Detects when a person wearing a bracelet walks through a doorway.            Includes:            1x Master sensor            1x Slave sensor            1x 5m Master-slave connection cable (CAT5)            1x Adjustment screwdriver            Requires 12VDC            Provides a 1 second momentary contact closure when triggered</p>
--	--

	<p><b>Extra Slave Sensor</b>            Extra Slave Sensors perform 2 functions:</p> <ul style="list-style-type: none"> <li>- Enable adjacent doorways to be monitored with 1 master, thereby reducing costs.</li> <li>- As a "blocking sensor" to block the detection zone from entering areas adjacent to the detection zone (see WanderShield Doorway manual for details). On some building layouts the omission of this can result in false alarms when a person walks through the detection zone in an adjacent room.</li> </ul>
--	---

	<p><b>Exterior Enclosure</b>            Protects doorway sensor from dust and moisture when mounting sensor on exterior of doorway (under an eave of suitable width). Resembles an exterior light.</p>
--	--

	<p><b>Exterior Enclosure with Boom</b>            Mounts doorway sensor the required distance away from a doorway when the eave above the exterior of a doorway is too narrow. Resembles an exterior light. Boom length = 1m.</p>
--	---

Product Code	Name & Description
--------------	--------------------

LOC-DS-001

**Doorway Sounder**



Provides audible alarm at doorway when wandering is detected. Alarm is reset by pressing reset button.

Includes:  
1x Doorway Sounder/Reset Unit  
1x 12VDC AC Adaptor

Provides clean contact output for integration with other systems.  
Includes separate reset input for connection to other systems or keypad.

LOC-DS-002

**Doorway Sounder with Wireless Transmitter**



Provides audible alarm at doorway when wandering is detected. Alarm is reset by pressing reset button.

This model transmits to Wireless Display (shown below).

Includes:  
1x Doorway Sounder/Reset Unit  
1x 12VDC AC Adaptor  
1x Built in wireless transmitter

Includes separate reset input for connection to other systems or keypad.

LOC-RX-001

**Wireless Display for Doorways**



Displays wander alarms from up to 16 doorways.  
Provides audible alarm and shows which doorway has been triggered on an 8 character LCD display. Name of each doorway is customisable.  
Provides 1x global clean contact output (activates when any door is triggered)

Works with LOC-DS-002 (shown above).

Includes:  
1x 12VDC AC Adaptor

LOC-RP-001

**Wireless Repeater**



Increases maximum distance between wireless Doorway Sounder and Wireless Display. Multiple repeaters can be used to cover entire buildings and campuses.

Includes:  
1x 12VDC AC Adaptor

## WanderShield Driveway

LOC-WDRIVE-001

**WanderShield Driveway Sensor**



Detects when a person wearing a bracelet approaches a driveway or gate.  
Detection zone is a 6m radius around driveway sensor.

Solar powered - requires no cabling  
Requires Wireless Receiver LOC-RX-002 (shown below)

LOC-RX-002

**Wireless Receiver for Driveway Sensor**



Displays wander alarms from up to 4 driveways  
Provides audible alarm and shows which driveway has been triggered.  
Provides 1x global clean contact output (activates when any driveway is triggered)

Driveway alarm is reset by pressing reset button on Wireless Receiver.

Includes:  
1x 12VDC AC Adaptor